



BarTrack®

BarTrack Cellular USB Modem Connection Instructions

BARTRACK CELLULAR USB MODEM CONNECTION INSTRUCTIONS

1.

Ensure BarTrack BCM is powered on.



2.

Unbox cellular USB-C Modem.



3.

Plug in USB-C to Modem.



4.

Plug in USB-C to USB Adaptor.



5.

Plug in Modem USB to BarTrack BCM.



6.

Ensure that System LED Indicator is Illuminated.



- Solid Yellow: Powering Up
- Solid Green: Registered on Network
- Solid Red: Error

7.

Ensure that Signal LED Indicator is Illuminated.



- Solid Green: Strong Signal Strength
- Solid Yellow: Acceptable Signal Strength
- Solid Red: No Signal