

Ensure the BarTrack BCM is plugged in





Ensure the Cellular Device is plugged into the USB port on the **BCM**






Wait until you see a solid green light & a solid orange light illuminated before beginning the set up process



Scan QR Code





Open Terms & Conditions




Accept Terms & Conditions


Retrofits | Rev. 0 1.



















Retrofits | Rev. 0



















Retrofits | Rev. 0



















Retrofits | Rev. 0 5.



















Retrofits | Rev. 0 6.











Retrofits | Rev. 0 7.